

Home Page
To get to home page turn the key clockwise



Press enter once and use the arrows to set to the current. Hold enter for 3 beeps to save changes

Programing Date
Hold left hand arrows for 3 beeps

Programing cycle Date
Hold right hand arrows for 3 beeps

This is the time of day a test cycle will run. We recommend you leave it at 12 midday. Providing this is ok hold the right hand arrow for 3 beeps



Hold left hand arrow for 3 beeps



Press enter once to edit the cycle date. Change the test cycle date to 28, this will ensure the test runs on the same day of the week every time



Press enter once and use the arrows to set to the current date. Hold enter for 3 beeps to save changes. Switch the key on and off to take you back to the home page