

AE-217 Smart Pressure Switch Instruction Manual

Product Description

The AE-217 smart pressure switch is an intelligent digital display pressure measurement and control product integrating pressure measurement, display, and output control. The product is a fully electronic structure, which measures and controls the pressure of the control system. The intelligent pressure switch is flexible to use, simple to operate, easy to debug, safe and reliable. Widely used in hydropower, tap water, petroleum, chemical, machinery, hydraulic and other industries to measure, display and control the pressure of fluid media

Technical Parameters

Table1 Parameter List

Parame ter	Parameter Value	Param eter	Parameter Value				
Measurin g Range	-1~0-0.2~1000bar	Measure ment Accurac	≤±0.25%、0.5%FS				
Stability	≤0.2% /year	Display Method	4-digit digital tube unit display				
Type of pressure			-1999~9999				
Overload capacity	1.5times full scale	Maximum power consumpt ion	≤1W				
Power supply	15~36V.DC	PL	IP65				
Switch load capacit y	< 1.2A(24V.DC)	Output	2 switch quantity (PNP/NPN)+4~ 20mA				
Load resistanc e	≤(U-12)/0.02Ω						
Switch life	> 10years	Respons e time	≤5ms				
Medium temperat ure	nperat -40°C~85°C		-40°C~70°C				

Relative		Storage					
temperat	0~95%	tempera	-20°C~60°C				
ure		ture					
Temperat	Within the specific working temperature, the output						
	change≤±0.05% of the range for every 10°C change						
ure effect	in the ambient temperature						

Selection Guide

SeriesGuide		AE-217	-	Х	-	Х	х	-	х	-[Х	-	х	-	Х
Pressure	Gauge		1	G	1			1		İ					
Datum	Absolute Pressure		1	Α											
Pressure	bar			!	Ī	В									
Unit	MPa				1	М									
	kPa					K									
Range	Pressure Range Value x X														
	G1/4								G1/4						
Process	1/4NPT								1/4NPT						
Connect-	G1/2	G1/2 G1/2													
ion	M20×1.5 M20														
	R1/4 R1/4						R1/4								
	R1/2 R1/2						R1/2								
	1/2NPT 1/2NPT							l							
	1 channel PNP+4-	20mA outp	out								Н1				
	2 channel PNP out	put									H2				
Output	2 channel PNP+4-20mA output H3						Н3								
Signal	1 channel NPN+4-20mA output H4														
	2 channel NPN output								Н5						
	2 channel NPN+4-20mA output							ſ	Н6						
Accuracy	0.5%FS														
Class	0.25%FS							2A							
Special	Please consult for other special requirements														

Dimensions



Electrical Wiring & Settings

1) Pin Definition

AE-217 smart pressure switch adopts two types of M12 sensor special connector with high protection level and direct wire outlet. The definition of each pin of M12 connector 4-core, 5-core and direct lead mode is shown in Figure 5-1.

AE-217 Smart Pressure Switch Instruction Manual






Figure 5-1 Terminal definition

2) Electrical wiring (this wiring diagram is a schematic diagram, the field wiring should be subject to the actual product)

a) PNP output wiring diagram is shown in Figure 5-

2, 5-3, 5-4




Figure 5-2 1 channel PNP+4 ~ 20mA analog signal output (4-wire system)




Figure 5-3 2 channel PNP output, no analog signal output (4-wire




Figure 5-4 2 channel PNP+4~20mAanalog signal output (5-wire system)

b) NPN the wiring diagram is shown in Figure 5-5,5-6,5-7




Figure 5-5 1 channel NPN+4~20mAanalog signal output (4-wire system)




Figure 5-6 2channel NPN output, no analog signal (4-wire




Figure 5-7 2 channel NPN+4~20mA analog signal output (5-wie system)

Please note that when installing the controller, the cables should be connected correctly according to the wiring diagram. If a shielded cable is used, connect the shielding layer to the shielded ground and ensure a reliable connection. The DC power supplied by the switch should be routed separately from the strong current cables, and try to avoid parallel routing at close distances.

2) On-site setting

a) Switch output description

AE-217 smart pressure switch has 1~2 (optional) switch output. Each switch output can set a pressure switch point and a set of opening and closing delay values. The corresponding output will switch when the pull-in value of the switch point is reached and resume when the pressure drops below the release value.

b) Analog output description

Provide one analog output (can be selected according to the model). It can output 4 \sim 20mA analog signal, corresponding to full scale pressure range

AE-217 Smart Pressure Switch Instruction Manual



c) Set the switching point action limit. Take 2 switch output example (1 switch output follows the same method)



Figure 5-5 Switch point setting flow chart

Table 3 Setting Parameters

Parameter name		Parameter	Predetermined	Factory
		meaning	area	default
AL1H		Switch 1 pull-in	0. 100% range	
	ALIH	value	0~100%range	
	AL1F	Switch 1 release	0. 100% range	
Common	ALIF	value	0~100%range	
parameters	AL1D	Switch 1 action	0-30\$	
	ALID	delay	0-303	
Password	AL2H	Switch 1 pull-in	0. 100% range	
0001	ALZH	value	0~100%range	
0001	AL2F	Switch 2 release	0~100%range	
	41.25	Switch 2 action	0.205	
	AL2D	delay	0-30\$	

Note: The switch point is determined by the pull-in value and the release value configuration. When the pull-in value is greater than the release value, it is the upper limit alarm output (normally open function), and when the pull-in value is less than the release value, it is the lower limit alarm output (normally closed function). The difference between the value and the release value is the hysteresis of the switching point.

Example: To set switch point 1 as the upper limit alarm output (normally open function) at 4.00MPa, and when it is less than 3.95MPa to disconnect, the switching delay is 3.0 seconds; switch point 2 is the lower limit alarm output (normally closed function) at When 10.00MPa is disconnected, if the suction is lower than 9.95MPa, the switching delay is 1.0 second:

Enter the menu, set

AL1H=4.00 AL1F=3.95 AL1D=3.0 AL2H=9.95 AL2F=10.00 AL2D=1.0

Description:

HHHH-- display the maximum value (>9999). After the data is normal, it will be automatically restored.

LLLL-- displays the minimum value (<-1999).

Automatically restores after data is normal.

Precautions

1) When installing the connecting cable, the power supply 24VDC to the instrument should be separated from the electrical cable, and try to avoid parallel wiring at close distances.

AD sampling, we solemnly remind users that the alarm speed of the switch is not as fast as possible. The choice of the alarm speed should be based on the need, in the balance between speed and stability. When the alarm speed is selected quickly, accidental fluctuations in the pressure signal or accidental interference burrs on the power supply may cause frequent alarms after being collected by the digital circuit. When the alarm speed is selected relatively slowly, the digital circuit can have sufficient time to correct the signal is subjected to interference removal filtering, and the stability can be greatly improved.

Operation & Maintenance

Operation:

- The user can put into operation without any adjustment of pressure switch. Before operation, check whether the installation and electrical connection are correct, turn on the power and put it into operation.
- 2. The pressure switch can work when the power is turned on, and the output signal is stable and reliable.

Maintenance:

AST-217 smart pressure switch is a high-precision measuring instrument. In daily maintenance, check whether the cable sheath is aging and cracked, and whether there is water ingress. If the pressure hole is blocked or the diaphragm is fouled, please clean it with a solvent compatible with the material of the pressure switch structure. Do not use a wire to poke the pressure hole or brush the diaphragm.





Attachment Description

Note:

AST-217 smart pressure switch should be stored in a dry and ventilated room with an ambient temperature of - 20~60°C and a relative humidity of not more than 95%. There should be no corrosive gas in the indoor air.



